EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001559
Project: PRJ-025
Uploaded on: 2024-11-14
Uploaded by: user196
Export class: ECCN-3A001

Assembly of P-102341 at plant PLT04

Part Number: P-102341
Revision: A.1
Plant: PLT04
Station: ST-62
Torque (Nm): 12
Cycle time (s): 255

Step 1: Torque to specification

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Clean mating surface

Assembly of P-101245 at plant PLT03

Part Number: P-101245
Revision: A.1
Plant: PLT03
Station: ST-43
Torque (Nm): 2.5
Cycle time (s): 231

Step 1: Apply thread locker

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Inspect incoming part