WORK INSTRUCTION

Document ID: DOC-0001563
Project: PRJ-021
Uploaded on: 2024-11-16
Uploaded by: user083
Export class: EAR99

Assembly of P-102335 at plant PLT04

Part Number: P-102335
Revision: A.1
Plant: PLT04
Station: ST-31
Torque (Nm): 2.5
Cycle time (s): 264

Step 1: Move to next station

Step 2: Torque to specification

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Torque to specification

Assembly of P-101141 at plant PLT02

Part Number: P-101141
Revision: A.1
Plant: PLT02
Station: ST-60
Torque (Nm): 8
Cycle time (s): 52

Step 1: Fit fasteners

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Torque to specification

Step 6: Visual check

Step 7: Apply thread locker