EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001567
Project: PRJ-010
Uploaded on: 2024-11-17
Uploaded by: user182
Export class: ECCN-3A001

Assembly of P-100560 at plant PLT01

Part Number: P-100560
Revision: A.1
Plant: PLT01
Station: ST-25
Torque (Nm): 2.5
Cycle time (s): 145

Step 1: Apply thread locker

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Fit fasteners

Assembly of P-100282 at plant PLT04

Part Number: P-100282
Revision: A.1
Plant: PLT04
Station: ST-50
Torque (Nm): 2.5
Cycle time (s): 161

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Inspect incoming part

Step 5: Move to next station

Step 6: Move to next station

Step 7: Fit fasteners

Assembly of P-101076 at plant PLT01

Part Number: P-101076
Revision: B.1
Plant: PLT01
Station: ST-42
Torque (Nm): 20

Cycle time (s): 178

Step 1: Record result

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Record result