WORK INSTRUCTION

Document ID: DOC-0001569
Project: PRJ-040
Uploaded on: 2024-11-19
Uploaded by: user028
Export class: EAR99

Assembly of P-102280 at plant PLT04

Part Number: P-102280
Revision: A.1
Plant: PLT04
Station: ST-77
Torque (Nm): 2.5
Cycle time (s): 72

Step 1: Visual check

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Record result

Step 5: Apply thread locker

Step 6: Record result

Step 7: Move to next station

Step 8: Fit fasteners

Assembly of P-100231 at plant PLT03

Part Number: P-100231
Revision: A.1
Plant: PLT03
Station: ST-83
Torque (Nm): 12
Cycle time (s): 131

Step 1: Visual check

Step 2: Clean mating surface

Step 3: Move to next station

Step 4: Torque to specification

Step 5: Clean mating surface

Step 6: Torque to specification

Step 7: Record result

Assembly of P-102215 at plant PLT02

Part Number: P-102215
Revision: A.1
Plant: PLT02
Station: ST-40

Torque (Nm):	8
Cycle time (s):	266

Step 1: Torque to specification

Step 2: Inspect incoming part

Step 3: Clean mating surface

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Apply thread locker

Step 7: Fit fasteners

Step 8: Record result