EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001571
Project: PRJ-012
Uploaded on: 2024-11-19
Uploaded by: user037
Export class: ECCN-3A001

Assembly of P-100569 at plant PLT03

Part Number: P-100569
Revision: A.1
Plant: PLT03
Station: ST-30
Torque (Nm): 5
Cycle time (s): 268

Step 1: Visual check

Step 2: Torque to specification

Step 3: Record result

Step 4: Record result

Step 5: Fit fasteners

Assembly of P-100039 at plant PLT02

Part Number: P-100039
Revision: A.1
Plant: PLT02
Station: ST-27
Torque (Nm): 5
Cycle time (s): 44

Step 1: Record result

Step 2: Torque to specification

Step 3: Record result

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Fit fasteners

Step 7: Clean mating surface

Assembly of P-100980 at plant PLT01

Part Number: P-100980
Revision: B.1
Plant: PLT01
Station: ST-10
Torque (Nm): 5

Cycle time (s): 86

Step 1: Clean mating surface

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Inspect incoming part

Step 5: Apply thread locker