WORK INSTRUCTION

Document ID: DOC-0001547
Project: PRJ-019
Uploaded on: 2024-11-10
Uploaded by: user103
Export class: EAR99

Assembly of P-101681 at plant PLT01

Part Number: P-101681
Revision: A.1
Plant: PLT01
Station: ST-75
Torque (Nm): 12
Cycle time (s): 155

Step 1: Record result

Step 2: Apply thread locker

Step 3: Apply thread locker

Step 4: Clean mating surface

Step 5: Clean mating surface

Step 6: Torque to specification

Step 7: Visual check

Step 8: Inspect incoming part

Assembly of P-100660 at plant PLT03

Part Number: P-100660
Revision: A.1
Plant: PLT03
Station: ST-81
Torque (Nm): 2.5
Cycle time (s): 127

Step 1: Inspect incoming part

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Visual check

Step 5: Record result

Step 6: Clean mating surface

Step 7: Apply thread locker

Step 8: Visual check

Assembly of P-101119 at plant PLT01

Part Number: P-101119
Revision: B.1
Plant: PLT01

Station: ST-12
Torque (Nm): 2.5
Cycle time (s): 99

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Torque to specification

Step 4: Torque to specification

Step 5: Visual check