WORK INSTRUCTION

Document ID: DOC-0001290
Project: PRJ-026
Uploaded on: 2024-07-23
Uploaded by: user011
Export class: EAR99

Assembly of P-100816 at plant PLT03

Part Number: P-100816
Revision: A.1
Plant: PLT03
Station: ST-53
Torque (Nm): 5
Cycle time (s): 267

Step 1: Visual check

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Record result

Step 5: Record result

Step 6: Clean mating surface

Step 7: Visual check

Step 8: Fit fasteners

Assembly of P-101392 at plant PLT02

Part Number: P-101392
Revision: A.1
Plant: PLT02
Station: ST-55
Torque (Nm): 20
Cycle time (s): 121

Step 1: Apply thread locker

Step 2: Record result

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Visual check

Step 6: Torque to specification

Step 7: Visual check