WORK INSTRUCTION

Document ID: DOC-0000928
Project: PRJ-039
Uploaded on: 2024-02-02
Uploaded by: user006
Export class: EAR99

Assembly of P-101180 at plant PLT03

Part Number: P-101180
Revision: A.1
Plant: PLT03
Station: ST-44
Torque (Nm): 20
Cycle time (s): 71

Step 1: Apply thread locker

Step 2: Visual check

Step 3: Move to next station

Step 4: Record result

Step 5: Fit fasteners

Step 6: Clean mating surface

Step 7: Move to next station

Step 8: Move to next station

Assembly of P-101530 at plant PLT01

Part Number: P-101530
Revision: A.1
Plant: PLT01
Station: ST-45
Torque (Nm): 20
Cycle time (s): 150

Step 1: Inspect incoming part

Step 2: Move to next station

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Move to next station

Step 6: Apply thread locker

Step 7: Visual check

Step 8: Visual check

Assembly of P-100304 at plant PLT02

Part Number: P-100304
Revision: A.1
Plant: PLT02

Station:	ST-69
Torque (Nm):	5
Cycle time (s):	172

Step 1: Clean mating surface

Step 2: Visual check

Step 3: Torque to specification

Step 4: Move to next station

Step 5: Torque to specification

Step 6: Fit fasteners