WORK INSTRUCTION

Document ID: DOC-0001830
Project: PRJ-016
Uploaded on: 2025-03-21
Uploaded by: user196
Export class: EAR99

Assembly of P-100599 at plant PLT01

Part Number: P-100599
Revision: A.1
Plant: PLT01
Station: ST-45
Torque (Nm): 20
Cycle time (s): 112

Step 1: Clean mating surface

Step 2: Inspect incoming part

Step 3: Record result

Step 4: Visual check

Step 5: Visual check

Step 6: Inspect incoming part

Step 7: Record result

Step 8: Fit fasteners

Assembly of P-102221 at plant PLT03

Part Number: P-102221
Revision: A.1
Plant: PLT03
Station: ST-55
Torque (Nm): 2.5
Cycle time (s): 183

Step 1: Apply thread locker

Step 2: Clean mating surface

Step 3: Record result

Step 4: Visual check

Step 5: Inspect incoming part

Step 6: Apply thread locker

Assembly of P-100968 at plant PLT02

Part Number: P-100968
Revision: A.1
Plant: PLT02
Station: ST-29
Torque (Nm): 5

Cycle time (s): 141

Step 1: Apply thread locker

Step 2: Move to next station

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Torque to specification

Step 6: Record result

Step 7: Fit fasteners