WORK INSTRUCTION

Document ID: DOC-0001768
Project: PRJ-009
Uploaded on: 2025-02-23
Uploaded by: user129
Export class: EAR99

Assembly of P-102563 at plant PLT01

Part Number: P-102563
Revision: A.1
Plant: PLT01
Station: ST-76
Torque (Nm): 2.5
Cycle time (s): 113

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Fit fasteners

Step 4: Torque to specification

Step 5: Clean mating surface

Assembly of P-100459 at plant PLT01

Part Number: P-100459
Revision: B.1
Plant: PLT01
Station: ST-36
Torque (Nm): 12
Cycle time (s): 202

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Torque to specification

Step 6: Clean mating surface

Step 7: Record result

Step 8: Apply thread locker