WORK INSTRUCTION

Document ID: DOC-0001788
Project: PRJ-030
Uploaded on: 2025-03-04
Uploaded by: user074
Export class: EAR99

Assembly of P-101042 at plant PLT02

Part Number: P-101042
Revision: A.1
Plant: PLT02
Station: ST-40
Torque (Nm): 8
Cycle time (s): 159

Step 1: Record result

Step 2: Inspect incoming part

Step 3: Record result

Step 4: Record result

Step 5: Apply thread locker

Step 6: Inspect incoming part

Step 7: Apply thread locker

Step 8: Record result

Assembly of P-102596 at plant PLT01

Part Number: P-102596
Revision: A.1
Plant: PLT01
Station: ST-33
Torque (Nm): 5
Cycle time (s): 271

Step 1: Clean mating surface

Step 2: Record result

Step 3: Apply thread locker

Step 4: Clean mating surface

Step 5: Clean mating surface

Step 6: Move to next station

Step 7: Inspect incoming part

Step 8: Apply thread locker