WORK INSTRUCTION

Document ID: DOC-0002809
Project: PRJ-006
Uploaded on: 2026-07-03
Uploaded by: user113
Export class: EAR99

Assembly of P-103025 at plant PLT04

Part Number: P-103025
Revision: A.1
Plant: PLT04
Station: ST-96
Torque (Nm): 8
Cycle time (s): 109

Step 1: Inspect incoming part

Step 2: Inspect incoming part

Step 3: Inspect incoming part

Step 4: Fit fasteners

Step 5: Fit fasteners

Step 6: Visual check

Assembly of P-102627 at plant PLT01

Part Number: P-102627
Revision: A.1
Plant: PLT01
Station: ST-62
Torque (Nm): 12
Cycle time (s): 268

Step 1: Apply thread locker

Step 2: Inspect incoming part

Step 3: Record result

Step 4: Torque to specification

Step 5: Clean mating surface

Step 6: Move to next station

Step 7: Inspect incoming part

Step 8: Fit fasteners

Assembly of P-101990 at plant PLT01

Part Number: P-101990
Revision: A.1
Plant: PLT01
Station: ST-10
Torque (Nm): 12

Cycle time (s): 243

Step 1: Move to next station

Step 2: Apply thread locker

Step 3: Move to next station

Step 4: Torque to specification

Step 5: Clean mating surface