WORK INSTRUCTION

Document ID: DOC-0002819
Project: PRJ-034
Uploaded on: 2026-07-08
Uploaded by: user016
Export class: EAR99

Assembly of P-103887 at plant PLT01

Part Number: P-103887
Revision: A.1
Plant: PLT01
Station: ST-42
Torque (Nm): 2.5
Cycle time (s): 173

Step 1: Clean mating surface

Step 2: Torque to specification

Step 3: Apply thread locker

Step 4: Record result

Step 5: Fit fasteners

Step 6: Record result

Assembly of P-104467 at plant PLT03

Part Number: P-104467
Revision: A.1
Plant: PLT03
Station: ST-15
Torque (Nm): 20
Cycle time (s): 245

Step 1: Move to next station

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Clean mating surface

Step 5: Torque to specification

Assembly of P-102205 at plant PLT04

Part Number: P-102205
Revision: B.1
Plant: PLT04
Station: ST-98
Torque (Nm): 12
Cycle time (s): 256

Step 1: Torque to specification

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Move to next station

Step 7: Clean mating surface