EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002351
Project: PRJ-015
Uploaded on: 2025-11-29
Uploaded by: user043
Export class: ECCN-3A001

Assembly of P-101161 at plant PLT02

Part Number: P-101161
Revision: A.1
Plant: PLT02
Station: ST-17
Torque (Nm): 8
Cycle time (s): 273

Step 1: Clean mating surface

Step 2: Record result

Step 3: Record result

Step 4: Inspect incoming part

Step 5: Torque to specification

Step 6: Torque to specification

Step 7: Fit fasteners

Assembly of P-103719 at plant PLT03

Part Number: P-103719
Revision: A.1
Plant: PLT03
Station: ST-51
Torque (Nm): 20
Cycle time (s): 212

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Visual check

Step 7: Clean mating surface

Assembly of P-100917 at plant PLT03

Part Number: P-100917
Revision: A.1
Plant: PLT03

Station:	ST-63
Torque (Nm):	8
Cycle time (s):	193

Step 1: Torque to specification

Step 2: Visual check

Step 3: Record result

Step 4: Inspect incoming part

Step 5: Record result

Step 6: Torque to specification