EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002388
Project: PRJ-001
Uploaded on: 2025-12-16
Uploaded by: user147
Export class: ECCN-3A001

Assembly of P-100441 at plant PLT01

Part Number: P-100441
Revision: B.1
Plant: PLT01
Station: ST-83
Torque (Nm): 20
Cycle time (s): 184

Step 1: Record result

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Torque to specification

Step 5: Move to next station

Step 6: Apply thread locker

Step 7: Visual check

Step 8: Visual check

Assembly of P-102754 at plant PLT01

Part Number: P-102754
Revision: A.1
Plant: PLT01
Station: ST-30
Torque (Nm): 2.5
Cycle time (s): 30

Step 1: Visual check

Step 2: Inspect incoming part

Step 3: Clean mating surface

Step 4: Torque to specification

Step 5: Apply thread locker

Step 6: Record result

Assembly of P-101249 at plant PLT03

Part Number: P-101249
Revision: A.1
Plant: PLT03

Station:	ST-27
Torque (Nm):	12
Cycle time (s):	125

Step 1: Fit fasteners

Step 2: Clean mating surface

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Visual check

Step 6: Torque to specification

Step 7: Fit fasteners