WORK INSTRUCTION

Document ID: DOC-0000840
Project: PRJ-033
Uploaded on: 2023-12-11
Uploaded by: user194
Export class: EAR99

Assembly of P-100136 at plant PLT02

Part Number: P-100136
Revision: C.1
Plant: PLT02
Station: ST-60
Torque (Nm): 8
Cycle time (s): 102

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Inspect incoming part

Step 5: Apply thread locker

Step 6: Record result

Step 7: Torque to specification

Step 8: Move to next station

Assembly of P-100920 at plant PLT03

Part Number: P-100920
Revision: A.1
Plant: PLT03
Station: ST-54
Torque (Nm): 20
Cycle time (s): 163

Step 1: Fit fasteners

Step 2: Fit fasteners

Step 3: Visual check

Step 4: Apply thread locker

Step 5: Apply thread locker

Step 6: Visual check

Step 7: Inspect incoming part

Step 8: Clean mating surface

Assembly of P-101218 at plant PLT03

Part Number: P-101218
Revision: A.1
Plant: PLT03

Station:	ST-94
Torque (Nm):	20
Cycle time (s):	228

Step 1: Move to next station

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Inspect incoming part

Step 5: Record result

Step 6: Inspect incoming part