WORK INSTRUCTION

Document ID: DOC-0001304
Project: PRJ-017
Uploaded on: 2024-07-29
Uploaded by: user150
Export class: EAR99

Assembly of P-101476 at plant PLT03

Part Number: P-101476
Revision: A.1
Plant: PLT03
Station: ST-29
Torque (Nm): 20
Cycle time (s): 69

Step 1: Visual check

Step 2: Move to next station

Step 3: Record result

Step 4: Torque to specification

Step 5: Apply thread locker

Step 6: Move to next station

Step 7: Visual check

Assembly of P-102012 at plant PLT02

Part Number: P-102012
Revision: A.1
Plant: PLT02
Station: ST-85
Torque (Nm): 5
Cycle time (s): 160

Step 1: Record result

Step 2: Visual check

Step 3: Visual check

Step 4: Torque to specification

Step 5: Move to next station

Step 6: Move to next station

Assembly of P-101047 at plant PLT03

Part Number: P-101047
Revision: A.1
Plant: PLT03
Station: ST-68
Torque (Nm): 8
Cycle time (s): 236

Step 1: Inspect incoming part

Step 2: Record result

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Fit fasteners