EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001309
Project: PRJ-003
Uploaded on: 2024-07-30
Uploaded by: user120
Export class: ECCN-3A001

Assembly of P-101598 at plant PLT01

Part Number: P-101598
Revision: A.1
Plant: PLT01
Station: ST-29
Torque (Nm): 12
Cycle time (s): 244

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Visual check

Step 4: Move to next station

Step 5: Clean mating surface

Assembly of P-101641 at plant PLT03

Part Number: P-101641
Revision: A.1
Plant: PLT03
Station: ST-80
Torque (Nm): 5
Cycle time (s): 97

Step 1: Record result

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Clean mating surface

Step 5: Clean mating surface

Step 6: Visual check

Step 7: Inspect incoming part

Step 8: Record result

Assembly of P-100481 at plant PLT02

Part Number: P-100481
Revision: A.1
Plant: PLT02
Station: ST-94

Torque (Nm):	8
Cycle time (s):	154

Step 1: Apply thread locker

Step 2: Torque to specification

Step 3: Clean mating surface

Step 4: Torque to specification

Step 5: Inspect incoming part