WORK INSTRUCTION

Document ID: DOC-0001310
Project: PRJ-030
Uploaded on: 2024-07-30
Uploaded by: user158
Export class: EAR99

Assembly of P-101752 at plant PLT02

Part Number: P-101752
Revision: A.1
Plant: PLT02
Station: ST-72
Torque (Nm): 20
Cycle time (s): 162

Step 1: Record result

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Record result

Step 6: Apply thread locker

Assembly of P-101380 at plant PLT02

Part Number: P-101380
Revision: A.1
Plant: PLT02
Station: ST-34
Torque (Nm): 8
Cycle time (s): 129

Step 1: Apply thread locker

Step 2: Record result

Step 3: Move to next station

Step 4: Move to next station

Step 5: Torque to specification

Assembly of P-100432 at plant PLT03

Part Number: P-100432
Revision: A.1
Plant: PLT03
Station: ST-74
Torque (Nm): 2.5
Cycle time (s): 110

Step 1: Clean mating surface

Step 2: Fit fasteners

Step 3: Torque to specification

Step 4: Torque to specification

Step 5: Move to next station

Step 6: Clean mating surface

Step 7: Clean mating surface