WORK INSTRUCTION

Document ID: DOC-0001315
Project: PRJ-007
Uploaded on: 2024-07-31
Uploaded by: user108
Export class: EAR99

Assembly of P-101942 at plant PLT01

Part Number: P-101942
Revision: A.1
Plant: PLT01
Station: ST-97
Torque (Nm): 12
Cycle time (s): 88

Step 1: Apply thread locker

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Torque to specification

Step 6: Clean mating surface

Step 7: Record result

Step 8: Torque to specification

Assembly of P-100375 at plant PLT04

Part Number: P-100375
Revision: A.1
Plant: PLT04
Station: ST-12
Torque (Nm): 2.5
Cycle time (s): 44

Step 1: Inspect incoming part

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Inspect incoming part

Step 5: Clean mating surface