WORK INSTRUCTION

Document ID: DOC-0000373
Project: PRJ-003
Uploaded on: 2023-04-28
Uploaded by: user154
Export class: EAR99

Assembly of P-100114 at plant PLT01

Part Number: P-100114
Revision: A.1
Plant: PLT01
Station: ST-85
Torque (Nm): 5
Cycle time (s): 128

Step 1: Visual check

Step 2: Fit fasteners

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Record result

Step 6: Clean mating surface

Step 7: Record result

Assembly of P-100357 at plant PLT04

Part Number: P-100357
Revision: A.1
Plant: PLT04
Station: ST-65
Torque (Nm): 20
Cycle time (s): 234

Step 1: Torque to specification

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Visual check

Step 5: Fit fasteners

Step 6: Move to next station

Step 7: Apply thread locker

Step 8: Visual check