WORK INSTRUCTION

Document ID: DOC-0002630
Project: PRJ-010
Uploaded on: 2026-04-06
Uploaded by: user009
Export class: EAR99

Assembly of P-103196 at plant PLT02

Part Number: P-103196
Revision: A.1
Plant: PLT02
Station: ST-18
Torque (Nm): 20
Cycle time (s): 100

Step 1: Inspect incoming part

Step 2: Apply thread locker

Step 3: Fit fasteners

Step 4: Torque to specification

Step 5: Apply thread locker

Assembly of P-102596 at plant PLT01

Part Number: P-102596
Revision: A.1
Plant: PLT01
Station: ST-59
Torque (Nm): 2.5
Cycle time (s): 174

Step 1: Move to next station

Step 2: Clean mating surface

Step 3: Torque to specification

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Clean mating surface

Step 7: Record result

Step 8: Inspect incoming part

Assembly of P-100572 at plant PLT01

Part Number: P-100572
Revision: B.1
Plant: PLT01
Station: ST-42
Torque (Nm): 12
Cycle time (s): 269

Step 1: Record result

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Torque to specification