EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002668
Project: PRJ-034
Uploaded on: 2026-04-21
Uploaded by: user004
Export class: ECCN-3A001

Assembly of P-103275 at plant PLT01

Part Number: P-103275
Revision: A.1
Plant: PLT01
Station: ST-12
Torque (Nm): 5
Cycle time (s): 150

Step 1: Inspect incoming part

Step 2: Move to next station

Step 3: Visual check

Step 4: Move to next station

Step 5: Fit fasteners

Step 6: Move to next station

Assembly of P-100169 at plant PLT01

Part Number: P-100169
Revision: B.1
Plant: PLT01
Station: ST-93
Torque (Nm): 20
Cycle time (s): 156

Step 1: Clean mating surface

Step 2: Move to next station

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Apply thread locker

Step 6: Inspect incoming part

Step 7: Apply thread locker