# WORK INSTRUCTION

**Document ID:** DOC-0002974
**Project:** PRJ-031
**Uploaded on:** 2026-09-23
**Uploaded by:** user110
**Export class:** EAR99

## Assembly of P-102799 at plant PLT03

**Part Number:** P-102799
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-45
**Torque (Nm):** 5
**Cycle time (s):** 171

Step 1: Clean mating surface

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Record result

Step 5: Apply thread locker

Step 6: Clean mating surface

Step 7: Fit fasteners

## Assembly of P-103500 at plant PLT01

**Part Number:** P-103500
**Revision:** A.1
**Plant:** PLT01
**Station:** ST-16
**Torque (Nm):** 12
**Cycle time (s):** 87

Step 1: Clean mating surface

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Inspect incoming part

Step 5: Inspect incoming part