**EXPORT CONTROLLED - ECCN 3A001**

# WORK INSTRUCTION

**Document ID:** DOC-0003001
**Project:** PRJ-012
**Uploaded on:** 2026-10-06
**Uploaded by:** user093
**Export class:** ECCN-3A001

## Assembly of P-103681 at plant PLT04

**Part Number:** P-103681
**Revision:** A.1
**Plant:** PLT04
**Station:** ST-68
**Torque (Nm):** 20
**Cycle time (s):** 119

Step 1: Inspect incoming part

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Torque to specification

Step 6: Inspect incoming part

## Assembly of P-102388 at plant PLT04

**Part Number:** P-102388
**Revision:** A.1
**Plant:** PLT04
**Station:** ST-55
**Torque (Nm):** 12
**Cycle time (s):** 275

Step 1: Inspect incoming part

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Visual check

Step 6: Move to next station

## Assembly of P-102083 at plant PLT02

**Part Number:** P-102083
**Revision:** A.1
**Plant:** PLT02
**Station:** ST-45
**Torque (Nm):** 20

**Cycle time (s):** 215

Step 1: Clean mating surface

Step 2: Torque to specification

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Clean mating surface

Step 6: Visual check

Step 7: Record result

Step 8: Visual check