EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0003014
Project: PRJ-007
Uploaded on: 2026-10-14
Uploaded by: user079
Export class: ECCN-3A001

Assembly of P-101166 at plant PLT03

Part Number: P-101166
Revision: B.1
Plant: PLT03
Station: ST-41
Torque (Nm): 12
Cycle time (s): 275

Step 1: Clean mating surface

Step 2: Torque to specification

Step 3: Torque to specification

Step 4: Record result

Step 5: Torque to specification

Assembly of P-102191 at plant PLT03

Part Number: P-102191
Revision: A.1
Plant: PLT03
Station: ST-32
Torque (Nm): 20
Cycle time (s): 171

Step 1: Torque to specification

Step 2: Move to next station

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Move to next station

Assembly of P-100133 at plant PLT04

Part Number: P-100133
Revision: D.1
Plant: PLT04
Station: ST-32
Torque (Nm): 8
Cycle time (s): 30

Step 1: Visual check

Step 2: Record result

Step 3: Fit fasteners

Step 4: Move to next station

Step 5: Visual check

Step 6: Torque to specification

Step 7: Clean mating surface

Step 8: Move to next station