EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002140
Project: PRJ-023
Uploaded on: 2025-08-16
Uploaded by: user073
Export class: ECCN-3A001

Assembly of P-101161 at plant PLT02

Part Number: P-101161
Revision: A.1
Plant: PLT02
Station: ST-92
Torque (Nm): 5
Cycle time (s): 54

Step 1: Record result

Step 2: Apply thread locker

Step 3: Torque to specification

Step 4: Clean mating surface

Step 5: Fit fasteners

Step 6: Fit fasteners

Step 7: Fit fasteners

Step 8: Visual check

Assembly of P-102998 at plant PLT02

Part Number: P-102998
Revision: A.1
Plant: PLT02
Station: ST-95
Torque (Nm): 2.5
Cycle time (s): 244

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Record result

Step 4: Record result

Step 5: Clean mating surface

Step 6: Apply thread locker

Assembly of P-102746 at plant PLT04

Part Number: P-102746
Revision: A.1
Plant: PLT04

Station:	ST-92
Torque (Nm):	20
Cycle time (s):	121

Step 1: Visual check

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Record result

Step 6: Torque to specification

Step 7: Record result

Step 8: Visual check