WORK INSTRUCTION

Document ID: DOC-0002175
Project: PRJ-030
Uploaded on: 2025-09-07
Uploaded by: user055
Export class: EAR99

Assembly of P-102775 at plant PLT02

Part Number: P-102775
Revision: A.1
Plant: PLT02
Station: ST-66
Torque (Nm): 20
Cycle time (s): 121

Step 1: Visual check

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Clean mating surface

Assembly of P-102386 at plant PLT03

Part Number: P-102386
Revision: A.1
Plant: PLT03
Station: ST-84
Torque (Nm): 8
Cycle time (s): 250

Step 1: Inspect incoming part

Step 2: Clean mating surface

Step 3: Inspect incoming part

Step 4: Inspect incoming part

Step 5: Torque to specification

Step 6: Apply thread locker

Step 7: Record result

Step 8: Clean mating surface