WORK INSTRUCTION

Document ID: DOC-0001367
Project: PRJ-030
Uploaded on: 2024-08-23
Uploaded by: user033
Export class: EAR99

Assembly of P-100454 at plant PLT03

Part Number: P-100454
Revision: A.1
Plant: PLT03
Station: ST-38
Torque (Nm): 8
Cycle time (s): 119

Step 1: Fit fasteners

Step 2: Fit fasteners

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Move to next station

Step 6: Torque to specification

Step 7: Clean mating surface

Assembly of P-100222 at plant PLT03

Part Number: P-100222
Revision: A.1
Plant: PLT03
Station: ST-53
Torque (Nm): 8
Cycle time (s): 38

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Record result

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Torque to specification

Step 7: Apply thread locker