# WORK INSTRUCTION

**Document ID:** DOC-0001405
**Project:** PRJ-024
**Uploaded on:** 2024-09-09
**Uploaded by:** user180
**Export class:** EAR99

## Assembly of P-101376 at plant PLT03

**Part Number:** P-101376
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-28
**Torque (Nm):** 8
**Cycle time (s):** 52

Step 1: Record result

Step 2: Apply thread locker

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Record result

Step 6: Torque to specification

Step 7: Move to next station

## Assembly of P-100710 at plant PLT03

**Part Number:** P-100710
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-77
**Torque (Nm):** 20
**Cycle time (s):** 133

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Fit fasteners

Step 4: Move to next station

Step 5: Clean mating surface

Step 6: Apply thread locker

Step 7: Inspect incoming part

## Assembly of P-101465 at plant PLT02

**Part Number:** P-101465
**Revision:** A.1
**Plant:** PLT02
**Station:** ST-58
**Torque (Nm):** 8

**Cycle time (s):** 122

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Visual check

Step 4: Clean mating surface

Step 5: Apply thread locker

Step 6: Clean mating surface

Step 7: Fit fasteners

Step 8: Record result