WORK INSTRUCTION

Document ID: DOC-0001406
Project: PRJ-033
Uploaded on: 2024-09-09
Uploaded by: user196
Export class: EAR99

Assembly of P-100743 at plant PLT01

Part Number: P-100743
Revision: A.1
Plant: PLT01
Station: ST-16
Torque (Nm): 5
Cycle time (s): 110

Step 1: Clean mating surface

Step 2: Move to next station

Step 3: Move to next station

Step 4: Visual check

Step 5: Torque to specification

Assembly of P-100134 at plant PLT01

Part Number: P-100134
Revision: B.1
Plant: PLT01
Station: ST-91
Torque (Nm): 2.5
Cycle time (s): 272

Step 1: Torque to specification

Step 2: Torque to specification

Step 3: Torque to specification

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Move to next station

Step 7: Apply thread locker

Step 8: Torque to specification

Assembly of P-100797 at plant PLT02

Part Number: P-100797
Revision: A.1
Plant: PLT02
Station: ST-94
Torque (Nm): 8
Cycle time (s): 100

Step 1: Visual check

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Visual check

Step 6: Clean mating surface

Step 7: Torque to specification