WORK INSTRUCTION

Document ID: DOC-0001086
Project: PRJ-017
Uploaded on: 2024-04-25
Uploaded by: user085
Export class: EAR99

Assembly of P-101129 at plant PLT01

Part Number: P-101129
Revision: A.1
Plant: PLT01
Station: ST-19
Torque (Nm): 2.5
Cycle time (s): 209

Step 1: Apply thread locker

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Fit fasteners

Step 6: Clean mating surface

Assembly of P-100559 at plant PLT03

Part Number: P-100559
Revision: B.1
Plant: PLT03
Station: ST-27
Torque (Nm): 5
Cycle time (s): 34

Step 1: Move to next station

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Move to next station

Step 6: Torque to specification

Step 7: Inspect incoming part

Step 8: Visual check