WORK INSTRUCTION

Document ID: DOC-0001102
Project: PRJ-007
Uploaded on: 2024-05-02
Uploaded by: user055
Export class: EAR99

Assembly of P-100803 at plant PLT03

Part Number: P-100803
Revision: A.1
Plant: PLT03
Station: ST-93
Torque (Nm): 8
Cycle time (s): 214

Step 1: Inspect incoming part

Step 2: Clean mating surface

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Apply thread locker

Step 6: Move to next station

Assembly of P-101674 at plant PLT02

Part Number: P-101674
Revision: A.1
Plant: PLT02
Station: ST-84
Torque (Nm): 20
Cycle time (s): 217

Step 1: Visual check

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Move to next station

Assembly of P-100777 at plant PLT01

Part Number: P-100777
Revision: A.1
Plant: PLT01
Station: ST-68
Torque (Nm): 8
Cycle time (s): 214

Step 1: Visual check

Step 2: Visual check

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Move to next station

Step 6: Fit fasteners

Step 7: Record result

Step 8: Clean mating surface