WORK INSTRUCTION

Document ID: DOC-0000481
Project: PRJ-032
Uploaded on: 2023-06-18
Uploaded by: user009
Export class: EAR99

Assembly of P-100636 at plant PLT04

Part Number: P-100636
Revision: A.1
Plant: PLT04
Station: ST-65
Torque (Nm): 8
Cycle time (s): 256

Step 1: Visual check

Step 2: Fit fasteners

Step 3: Visual check

Step 4: Move to next station

Step 5: Record result

Step 6: Move to next station

Step 7: Fit fasteners

Assembly of P-100555 at plant PLT04

Part Number: P-100555
Revision: A.1
Plant: PLT04
Station: ST-75
Torque (Nm): 20
Cycle time (s): 50

Step 1: Apply thread locker

Step 2: Move to next station

Step 3: Inspect incoming part

Step 4: Inspect incoming part

Step 5: Visual check

Step 6: Clean mating surface

Step 7: Clean mating surface

Step 8: Visual check

Assembly of P-100506 at plant PLT03

Part Number: P-100506
Revision: A.1
Plant: PLT03
Station: ST-68

Torque (Nm):	8
Cycle time (s):	219

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Record result

Step 4: Apply thread locker

Step 5: Apply thread locker

Step 6: Clean mating surface