WORK INSTRUCTION

Document ID: DOC-0000216
Project: PRJ-011
Uploaded on: 2023-02-16
Uploaded by: user049
Export class: EAR99

Assembly of P-100273 at plant PLT02

Part Number: P-100273
Revision: A.1
Plant: PLT02
Station: ST-96
Torque (Nm): 12
Cycle time (s): 155

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Fit fasteners

Step 4: Torque to specification

Step 5: Inspect incoming part

Step 6: Record result

Assembly of P-100122 at plant PLT03

Part Number: P-100122
Revision: A.1
Plant: PLT03
Station: ST-65
Torque (Nm): 20
Cycle time (s): 45

Step 1: Fit fasteners

Step 2: Inspect incoming part

Step 3: Torque to specification

Step 4: Move to next station

Step 5: Fit fasteners

Step 6: Apply thread locker

Step 7: Clean mating surface

Assembly of P-100221 at plant PLT01

Part Number: P-100221
Revision: A.1
Plant: PLT01
Station: ST-52
Torque (Nm): 12
Cycle time (s): 265

Step 1: Apply thread locker

Step 2: Visual check

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Record result

Step 6: Record result

Step 7: Torque to specification

Step 8: Clean mating surface