WORK INSTRUCTION

Document ID: DOC-0002866
Project: PRJ-020
Uploaded on: 2026-07-28
Uploaded by: user106
Export class: EAR99

Assembly of P-102336 at plant PLT03

Part Number: P-102336
Revision: A.1
Plant: PLT03
Station: ST-33
Torque (Nm): 20
Cycle time (s): 42

Step 1: Fit fasteners

Step 2: Record result

Step 3: Apply thread locker

Step 4: Move to next station

Step 5: Fit fasteners

Assembly of P-103656 at plant PLT04

Part Number: P-103656
Revision: A.1
Plant: PLT04
Station: ST-48
Torque (Nm): 12
Cycle time (s): 180

Step 1: Inspect incoming part

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Clean mating surface

Step 5: Clean mating surface

Step 6: Visual check

Step 7: Torque to specification

Step 8: Clean mating surface

Assembly of P-100926 at plant PLT01

Part Number: P-100926
Revision: B.1
Plant: PLT01
Station: ST-30
Torque (Nm): 5
Cycle time (s): 64

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Move to next station

Step 5: Record result