EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002882
Project: PRJ-007
Uploaded on: 2026-08-03
Uploaded by: user160
Export class: ECCN-3A001

Assembly of P-100708 at plant PLT01

Part Number: P-100708
Revision: A.1
Plant: PLT01
Station: ST-90
Torque (Nm): 8
Cycle time (s): 74

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Torque to specification

Step 6: Move to next station

Assembly of P-102299 at plant PLT01

Part Number: P-102299
Revision: A.1
Plant: PLT01
Station: ST-48
Torque (Nm): 20
Cycle time (s): 226

Step 1: Apply thread locker

Step 2: Record result

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Torque to specification

Assembly of P-102347 at plant PLT03

Part Number: P-102347
Revision: A.1
Plant: PLT03
Station: ST-39
Torque (Nm): 2.5

Cycle time (s): 121

Step 1: Fit fasteners

Step 2: Fit fasteners

Step 3: Record result

Step 4: Clean mating surface

Step 5: Apply thread locker

Step 6: Record result

Step 7: Torque to specification

Step 8: Torque to specification