WORK INSTRUCTION

Document ID: DOC-0000253
Project: PRJ-040
Uploaded on: 2023-03-04
Uploaded by: user055
Export class: EAR99

Assembly of P-100310 at plant PLT01

Part Number: P-100310
Revision: A.1
Plant: PLT01
Station: ST-16
Torque (Nm): 20
Cycle time (s): 106

Step 1: Torque to specification

Step 2: Move to next station

Step 3: Record result

Step 4: Torque to specification

Step 5: Move to next station

Step 6: Clean mating surface

Step 7: Torque to specification

Assembly of P-100354 at plant PLT02

Part Number: P-100354
Revision: A.1
Plant: PLT02
Station: ST-19
Torque (Nm): 12
Cycle time (s): 166

Step 1: Inspect incoming part

Step 2: Visual check

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Move to next station

Step 6: Clean mating surface

Step 7: Visual check

Step 8: Visual check

Assembly of P-100190 at plant PLT03

Part Number: P-100190
Revision: A.1
Plant: PLT03
Station: ST-83

Torque (Nm): 5
Cycle time (s): 167

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Record result

Step 6: Move to next station

Step 7: Inspect incoming part

Step 8: Fit fasteners