WORK INSTRUCTION

Document ID: DOC-0000258
Project: PRJ-030
Uploaded on: 2023-03-06
Uploaded by: user135
Export class: EAR99

Assembly of P-100031 at plant PLT03

Part Number: P-100031
Revision: B.1
Plant: PLT03
Station: ST-79
Torque (Nm): 5
Cycle time (s): 52

Step 1: Record result

Step 2: Fit fasteners

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Torque to specification

Step 7: Move to next station

Step 8: Torque to specification

Assembly of P-100335 at plant PLT04

Part Number: P-100335
Revision: A.1
Plant: PLT04
Station: ST-24
Torque (Nm): 8
Cycle time (s): 139

Step 1: Fit fasteners

Step 2: Torque to specification

Step 3: Clean mating surface

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Apply thread locker

Step 7: Torque to specification

Step 8: Inspect incoming part