WORK INSTRUCTION

Document ID: DOC-0002580
Project: PRJ-009
Uploaded on: 2026-03-11
Uploaded by: user010
Export class: EAR99

Assembly of P-103365 at plant PLT03

Part Number: P-103365
Revision: A.1
Plant: PLT03
Station: ST-68
Torque (Nm): 12
Cycle time (s): 103

Step 1: Inspect incoming part

Step 2: Fit fasteners

Step 3: Record result

Step 4: Record result

Step 5: Inspect incoming part

Step 6: Apply thread locker

Step 7: Clean mating surface

Step 8: Torque to specification

Assembly of P-100033 at plant PLT01

Part Number: P-100033
Revision: C.1
Plant: PLT01
Station: ST-19
Torque (Nm): 2.5
Cycle time (s): 251

Step 1: Record result

Step 2: Record result

Step 3: Record result

Step 4: Visual check

Step 5: Apply thread locker

Step 6: Record result

Assembly of P-101854 at plant PLT02

Part Number: P-101854
Revision: A.1
Plant: PLT02
Station: ST-27
Torque (Nm): 8

Cycle time (s): 272

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Clean mating surface

Step 5: Torque to specification

Step 6: Torque to specification