WORK INSTRUCTION

Document ID: DOC-0002592
Project: PRJ-013
Uploaded on: 2026-03-16
Uploaded by: user131
Export class: EAR99

Assembly of P-103513 at plant PLT01

Part Number: P-103513
Revision: A.1
Plant: PLT01
Station: ST-77
Torque (Nm): 12
Cycle time (s): 33

Step 1: Apply thread locker

Step 2: Apply thread locker

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Record result

Assembly of P-102314 at plant PLT01

Part Number: P-102314
Revision: A.1
Plant: PLT01
Station: ST-17
Torque (Nm): 12
Cycle time (s): 116

Step 1: Move to next station

Step 2: Record result

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Apply thread locker

Step 6: Torque to specification

Step 7: Visual check

Assembly of P-103996 at plant PLT01

Part Number: P-103996
Revision: A.1
Plant: PLT01
Station: ST-24
Torque (Nm): 2.5
Cycle time (s): 183

Step 1: Apply thread locker

Step 2: Torque to specification

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Record result

Step 6: Clean mating surface

Step 7: Move to next station