# WORK INSTRUCTION

**Document ID:** DOC-0001930
**Project:** PRJ-032
**Uploaded on:** 2025-05-14
**Uploaded by:** user001
**Export class:** EAR99

## Assembly of P-101068 at plant PLT02

**Part Number:** P-101068
**Revision:** A.1
**Plant:** PLT02
**Station:** ST-69
**Torque (Nm):** 20
**Cycle time (s):** 281

Step 1: Move to next station

Step 2: Apply thread locker

Step 3: Torque to specification

Step 4: Move to next station

Step 5: Inspect incoming part

Step 6: Clean mating surface

Step 7: Clean mating surface