EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001978
Project: PRJ-008
Uploaded on: 2025-06-03
Uploaded by: user116
Export class: ECCN-3A001

Assembly of P-102110 at plant PLT03

Part Number: P-102110
Revision: A.1
Plant: PLT03
Station: ST-77
Torque (Nm): 12
Cycle time (s): 279

Step 1: Torque to specification

Step 2: Visual check

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Record result

Step 6: Clean mating surface

Step 7: Move to next station

Step 8: Inspect incoming part

Assembly of P-102457 at plant PLT03

Part Number: P-102457
Revision: A.1
Plant: PLT03
Station: ST-22
Torque (Nm): 12
Cycle time (s): 33

Step 1: Record result

Step 2: Fit fasteners

Step 3: Clean mating surface

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Apply thread locker

Step 7: Torque to specification

Assembly of P-100343 at plant PLT03

Part Number: P-100343
Revision: B.1

Plant:	PLT03
Station:	ST-65
Torque (Nm):	2.5
Cycle time (s):	255

Step 1: Move to next station

Step 2: Visual check

Step 3: Inspect incoming part

Step 4: Fit fasteners

Step 5: Inspect incoming part

Step 6: Clean mating surface

Step 7: Move to next station

Step 8: Record result