WORK INSTRUCTION

Document ID: DOC-0001992
Project: PRJ-040
Uploaded on: 2025-06-09
Uploaded by: user052
Export class: EAR99

Assembly of P-100173 at plant PLT03

Part Number: P-100173
Revision: B.1
Plant: PLT03
Station: ST-34
Torque (Nm): 8
Cycle time (s): 83

Step 1: Clean mating surface

Step 2: Record result

Step 3: Clean mating surface

Step 4: Clean mating surface

Step 5: Record result

Assembly of P-101115 at plant PLT04

Part Number: P-101115
Revision: A.1
Plant: PLT04
Station: ST-84
Torque (Nm): 12
Cycle time (s): 220

Step 1: Inspect incoming part

Step 2: Torque to specification

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Apply thread locker