WORK INSTRUCTION

Document ID: DOC-0002913
Project: PRJ-032
Uploaded on: 2026-08-17
Uploaded by: user148
Export class: EAR99

Assembly of P-102217 at plant PLT02

Part Number: P-102217
Revision: A.1
Plant: PLT02
Station: ST-97
Torque (Nm): 5
Cycle time (s): 207

Step 1: Inspect incoming part

Step 2: Fit fasteners

Step 3: Fit fasteners

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Visual check

Step 7: Apply thread locker

Assembly of P-101703 at plant PLT02

Part Number: P-101703
Revision: A.1
Plant: PLT02
Station: ST-92
Torque (Nm): 20
Cycle time (s): 151

Step 1: Apply thread locker

Step 2: Record result

Step 3: Torque to specification

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Fit fasteners