WORK INSTRUCTION

Document ID: DOC-0002918
Project: PRJ-003
Uploaded on: 2026-08-20
Uploaded by: user181
Export class: EAR99

Assembly of P-102815 at plant PLT03

Part Number: P-102815
Revision: A.1
Plant: PLT03
Station: ST-99
Torque (Nm): 12
Cycle time (s): 101

Step 1: Torque to specification

Step 2: Apply thread locker

Step 3: Torque to specification

Step 4: Clean mating surface

Step 5: Inspect incoming part

Step 6: Torque to specification

Step 7: Move to next station

Step 8: Fit fasteners

Assembly of P-101213 at plant PLT04

Part Number: P-101213
Revision: A.1
Plant: PLT04
Station: ST-74
Torque (Nm): 5
Cycle time (s): 160

Step 1: Fit fasteners

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Move to next station

Step 6: Clean mating surface

Step 7: Fit fasteners