WORK INSTRUCTION

Document ID: DOC-0002921
Project: PRJ-030
Uploaded on: 2026-08-24
Uploaded by: user006
Export class: EAR99

Assembly of P-100002 at plant PLT03

Part Number: P-100002
Revision: D.1
Plant: PLT03
Station: ST-32
Torque (Nm): 8
Cycle time (s): 167

Step 1: Clean mating surface

Step 2: Move to next station

Step 3: Record result

Step 4: Fit fasteners

Step 5: Visual check

Assembly of P-104449 at plant PLT03

Part Number: P-104449
Revision: A.1
Plant: PLT03
Station: ST-78
Torque (Nm): 2.5
Cycle time (s): 174

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Clean mating surface

Step 4: Fit fasteners

Step 5: Visual check