EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002307
Project: PRJ-007
Uploaded on: 2025-11-08
Uploaded by: user177
Export class: ECCN-3A001

Assembly of P-103214 at plant PLT01

Part Number: P-103214
Revision: A.1
Plant: PLT01
Station: ST-22
Torque (Nm): 20
Cycle time (s): 277

Step 1: Torque to specification

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Torque to specification

Step 5: Clean mating surface

Step 6: Torque to specification

Step 7: Record result

Assembly of P-102900 at plant PLT04

Part Number: P-102900
Revision: A.1
Plant: PLT04
Station: ST-41
Torque (Nm): 8
Cycle time (s): 217

Step 1: Torque to specification

Step 2: Fit fasteners

Step 3: Torque to specification

Step 4: Torque to specification

Step 5: Clean mating surface

Step 6: Inspect incoming part

Step 7: Clean mating surface

Assembly of P-101854 at plant PLT02

Part Number: P-101854
Revision: A.1
Plant: PLT02

Station: ST-73
Torque (Nm): 12
Cycle time (s): 229

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Apply thread locker

Step 5: Record result

Step 6: Apply thread locker