WORK INSTRUCTION

Document ID: DOC-0002316
Project: PRJ-001
Uploaded on: 2025-11-11
Uploaded by: user157
Export class: EAR99

Assembly of P-103328 at plant PLT03

Part Number: P-103328
Revision: A.1
Plant: PLT03
Station: ST-48
Torque (Nm): 8
Cycle time (s): 139

Step 1: Clean mating surface

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Inspect incoming part

Step 5: Fit fasteners

Step 6: Apply thread locker

Step 7: Record result

Assembly of P-103701 at plant PLT03

Part Number: P-103701
Revision: A.1
Plant: PLT03
Station: ST-49
Torque (Nm): 12
Cycle time (s): 293

Step 1: Fit fasteners

Step 2: Fit fasteners

Step 3: Fit fasteners

Step 4: Move to next station

Step 5: Apply thread locker

Step 6: Torque to specification

Step 7: Inspect incoming part