WORK INSTRUCTION

Document ID: DOC-0002325
Project: PRJ-038
Uploaded on: 2025-11-15
Uploaded by: user194
Export class: EAR99

Assembly of P-101768 at plant PLT01

Part Number: P-101768
Revision: A.1
Plant: PLT01
Station: ST-63
Torque (Nm): 5
Cycle time (s): 77

Step 1: Record result

Step 2: Torque to specification

Step 3: Visual check

Step 4: Clean mating surface

Step 5: Fit fasteners

Step 6: Fit fasteners

Assembly of P-102584 at plant PLT03

Part Number: P-102584
Revision: A.1
Plant: PLT03
Station: ST-59
Torque (Nm): 5
Cycle time (s): 97

Step 1: Fit fasteners

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Fit fasteners

Step 5: Fit fasteners

Step 6: Clean mating surface

Assembly of P-101425 at plant PLT03

Part Number: P-101425
Revision: B.1
Plant: PLT03
Station: ST-42
Torque (Nm): 8
Cycle time (s): 283

Step 1: Apply thread locker

Step 2: Record result

Step 3: Inspect incoming part

Step 4: Move to next station

Step 5: Fit fasteners

Step 6: Inspect incoming part

Step 7: Clean mating surface